

Supplement to the user information

AquaControl +

Fill level measuring device and drinking water supply


Item-No.: 351021

8. Special functions:

8.1 Pump out:

8.1.1 Description:

Your device has been fitted with an additional Pump out function. This enables water to be pumped out of the main tank. The switching point “pump out” may be set as a menu point in the usual way.



- 1: System control
- 2: Additional pump
- 3: Second tank
- 4: Main tank
- 5: to house water supply
- 6: Sensor technology

Diagram 13: Plant layout example

8.1.2 Changes in the operation level:

The main menu level (see diagram 9) receives an additional menu point:




Diagram 14: Main menu level

The menu point “Special functions” has the following contents:




Diagram 15: Menu point “Special functions”

Remark:

The chosen numeric value “Pump off from” should always be greater than the numeric value “valve off”!

The water will be pumped off when it rises above the set value.

To prevent constant switching on and off of this function, it is pumped off to 2% under the opposed value.